



A successful path to interchangeability

Establishing a US-qualified digital X-ray capability for Guided Weapons and Explosive Ordnance (GWEO) types.

Roger Broughton
Production Engineer / Industrial Radiographer
NAS410 Level III RT
Australian Munitions



Agenda

- **Why conduct Radiography?**
- **How does Radiography fit into interchangeability**
- **Journey to achieve NAS410**
- **Film to digital transition**
- **Benalla facility**
- **Technique and Process Controls**
- **Conclusion**

Why conduct radiography on *artillery rounds*



Risk mitigation.
Function as designed,
when required.
Specs call for it.
Standards require it.
Normal process.

Source <https://www.quora.com/How-does-an-artillery-projectile-not-explode-and-destroy-the-artillery-that-fired-it>

Why conduct radiography on GWEO

Avoidance of Rapid Unscheduled Disassembly



Static firing surveillance test at DST Missile Test Area – Rocket motor explosion.

Source Space Autonomy Group, DSTG

How does Radiography fit into interchangeability

US Qualifications of locally produced Ordnance.

- More sophisticated US designed materiel being produced in Australia to meet sovereign capabilities and global demand.
- Required compliant processes and qualifications to produce.
- This includes NAS410 (US based Standard Practice) Certification and Qualification of NDT personnel.
- This allowed the Benalla site to transition towards digital with new products bypassing film and using digital immediately.

Source; <https://www.australian-munitions.com.au/australian-made-blu-111-bombs-enter-service/>



Journey to achieve NAS410

- Understanding of Standard Practice and Guides.
- Develop written practice & procedures.
- Procure and develop equipment to suit.
- On the Job Training (Film and Non-Film).
- Exams (General, Specific, and Practical).

Thales Benalla

- 155mm, initial start using film but quickly moved to digital.
 - Develop Techniques from Specs.
 - Incorporate into procedures
 - Process Controls
 - Shooting
 - Viewing and Sentencing
 - Reporting
 - Gain confidence in process
 - Participate in FAT, Exams, Audits, etc



Source <https://www.military.com/equipment/m198-howitzer>

References for X-ray Radiography



NAS410
ASTM-E1742
ASNT SNT-TC-1A
NCRP 144
ASTM-E747
ASTM-E999
ANSI/NCSL Z540-3
ASTM-E1165
ASTM-E1212
ASTM-E1390
ASTM-E2698
ASNT-CP-189
ASTM-E543
ASTM-E1316
ASTM-E94
ASTM-E1359
ASTM-E746
ASTM-E1416
ASTM-E1254
ASTM-E2737
ASTM-E2736
ISO 17636-2
AWS A2.4
ISO 10012
ISO 9712
ASTM-E1815
ASTM-E1032
ASTM-E1411
ASTM-E1030
ISO 5579
NCRP 116

Differences



- Higher capital costs with Digital Detector Array (DDA).
- Lower portability of DDA panels.
 - Bulky and “delicate”
- Increased process controls for DDA.
 - Proving stability with more complex tests.
- Faster throughput.
 - Automation.
 - No developing time/instant access to images.
- No messy and environmentally damaging chemicals and waste.
- Improved analysis capability to view images and detect indications.
- Storage on LAN forever, if required.

What can we shoot



- Wide range of X-ray capability.
 - Portable low energy unit, for remote imaging, is available.
- Items as small as Detonators and Grenade Fuzes, small arms Projectiles
- Large Projectiles
- Bombs
- Rocket Motors
- Other Defence products
- Other commercial products



Benalla facility capability




Porosity




Cracks



Slag Inclusion



Tungsten Inclusion



Indicative of defects found.

Source <https://www.orangecoasttesting.com/radiographic>

https://www.researchgate.net/figure/Example-of-weld-radiography-image-with-defects-porosities-circular-and-a-longitudinal_fig2_288480629

This document may not be reproduced, modified, adapted, published, translated, in any way, in whole or in part or disclosed to a third party without the prior written consent of Thales. © Thales 2022. All rights reserved.

Technique set up considerations

- Each product has its individual set up with considerations for safety, security, timing, quality, dimensions, etc.
- Dimensional factors such as Ug, Uim, Geo Mag, SDD, SOD, ESS, need to be considered
- Equipment stability
- Image Quality/Process Controls

<https://dptoys.tw/smpte+test+pattern+download>

Process Controls and Image Quality

Phantom used for process stability.



This document may not be reproduced, modified, adapted, published, transcribed, in any way, in whole or in part or disclosed to a third party without the prior written consent of Thales - © Thales 2024 All rights reserved.

Conclusion

- A Radiographers top priority is safety of all that associate with the store.
- More components are being manufactured in Australia to overseas specifications.
- New products developed in Australia, such as GWEO.
- Compliance to original specification is mandatory.
- Radiography assists in interchangeability.

Testing of a Thales manufactured 80kg NEQ 10-inch class, composite case, composite propellant solid rocket motor as part of the Advanced Rocket Motor Technology Demonstrator (ARMTD) Program at Woomera.



Thank you